



ARTS 7000 TCAS & UAT Activation Procedure

This procedure identifies the specific steps required to activate the TCAS and/or UAT functions in the ARTS 7000.



Items required:

- ARTS-7000 Test System
- ARTS-7000 iPad controller


ARTS-7000 TCAS Activation Procedure

1. Run the ARTS 7000 Application

- Open the ARTS 7000 Application.
- Press **Offline**.
- Enter the **Utilities** Menu and press **Permissions**.




- For TCAS: Within the Permissions menu, select **Add TCAS License**, then enter the letters "**LAV**" followed by the Serial Number of the ARTS-7000 unit.
- For UAT: Within the Permissions menu, select **Add UAT License**, then enter the letters "**LAV**" followed by the Serial Number of the ARTS-7000 unit.



2. License activated.

- a. After verification, the license will be stored on the iPad.
- b. Begin using the TCAS and/or UAT functions after connecting the iPad Wi-Fi to the ARTS-7000 unit.



3. Consult the online video.

- a. Should you have any questions, please review the online video [here](#) to see how the license is activated.